



207-594-1224

*info@CoastalMainePhotoTours.com*

*407 Main St. Rockland, Maine 04841*

## Focused Learning Options with Dee Peppe

### Getting to Know Your Camera

#### BODY

ON / OFF button  
Shutter button  
Main control wheel/ dial  
Exposure mode dial  
Viewfinder  
Dioptric adjustment  
Flash hot shoe  
Flash  
Flash button  
Timer  
Continuous Shooting  
Control keys  
Menu button  
Playback button  
Zoom/magnifier for playback  
Trash button  
Display or Info button  
Battery compartment  
Tripod socket  
Lens lock release  
Lens mount  
Depth of field preview button

#### LENS

Focus ring  
Focus mode switch (manual to auto)  
Lens stabilizer / Vibration eliminator  
Zoom ring  
Lens diaphragm / Aperture  
Focal length  
Aperture range

#### MENU ITEMS

Image quality  
Image size  
Color space  
Date/Time  
Formatting memory card  
Auto power time off  
Display screen time off  
LCD monitor brightness

#### QUICK BUTTONS

ISO  
White Balance  
Auto Focus  
Continuous shooting

#### DISPLAY ITEMS in LCD MONITOR

Shutter speed setting  
F-Stop setting  
ISO setting  
Light Meter  
Exposure mode  
White Balance  
Image size and quality  
Battery power  
Continuous Shooting or One Shot  
Counter

#### INTERIOR PARTS:

Mirror  
Focus screen  
Pantaprism  
Shutter

